

everlasting Flameless CANDLE


INSTRUCTIONS

1. Install 3 "AAA" batteries (included) into the bottom battery compartment. Make sure battery polarity (+/-) is as indicated. (see A)
2. To turn LED candle on move switch to the flicker position. (see B)
3. Switch to "off" when not in use.

Warning: The Candle is made from real wax. It is recommended that the wax candle be kept out of high heat environments and not placed directly on a porous surface. Heat may cause the candle to change shape, melt or bleed onto unprotected surfaces.

BATTERY NOTICE

Do not mix old and new batteries. Do not mix alkaline, standard (Carbon-Zinc), or rechargeable (Nickel Cadmium) batteries. Replace all batteries at one time. To avoid leakage or explosion, do not put batteries in fire. Remove batteries if consumed or if product is to be left unused for a long period of time. Clean the battery contacts and also those of the devices prior to battery installation.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced Radio TV technician for help.

Modifications not approved by the party responsible for compliance could void user's authority to operate this unit.



Mark Feldstein & Associates, inc.
Maumee, Ohio 43537 • www.markfeldstein.com

Simple Flickering Version_FCC Compliance_Batteries Included